



the **outdoor**
greatroom
company

The Cove Fire Pit

Installation Instructions for Round Cove Fire Pits
CVC-36, CVC-42, CVC-48, CVC-60, CVC-72



IMPORTANT

DO NOT ATTEMPT TO INSTALL CRYSTAL FIRE BURNER WITHOUT FIRST CONSULTING THE CRYSTAL FIRE OWNER’S MANUAL.

Please consult your Crystal Fire instruction manual for detailed instructions and important information related to the burner installation including lighting and operating instructions, safety information, and proper tightening of connections with two wrenches.

ENCLOSURE DESIGN REQUIREMENTS

The ventilation requirements for natural gas and propane hard-piped installations in the Crystal Fire Plus manual are intended for enclosures not designed and tested by The Outdoor GreatRoom Company and do not apply to The Cove Fire Pits.

Contents

Required Tools.....	3
Included with your Fire Pit.....	3
Assembly Instructions.....	4
Sparker Installation... ..	4
Gas Connections	5
Electrode Installation... ..	5
Burner Installation.....	6
Glass Media Installation.....	6
Frequently Asked Questions	8
Maintenance	9
Service Parts.....	11
Warranty.....	12

Required Tools

Four people are required for this installation.



- **2 Open Ended Wrenches**

To secure gas connections.



- **Leather Gloves**

To protect hands from rough edges found on fire pit during installation.



- **One AAA Battery (not included)**

Required for electric spark igniter installation.



- **Utility Knife**

To cut and remove packaging.



- **Power Drill**

To remove support board from crate.

Included With Your Fire Pit



Round Fire Pit with Control



Crystal Fire® Plus CFP20 Burner Kit for 36 and 42inch models, Crystal Fire® Plus CFP30 Burner Kit for 48, 60 and 72 inch models.

Assembly Instructions

- Remove Cove Fire Pit Base from Packaging crate


- Four People are required to lift base out of packaging and place into final location.



See your **Crystal Fire Plus Owner's Manual** for gas and electric requirements for electronic ignition (DSI) burners.

- Sparker Installation

- Remove sparker cap and hex nut. Insert AAA battery (not included) with + end out.
- Install sparker into control panel as shown below, secure using hex nut and replace sparker cap.
- Depress sparker button to ensure your sparker is working properly. You should hear the spark behind the sparker box.




Locate and orient sparker box on control panel as shown. Sparker box must be installed **before** burner valve.


- **Gas Connections**

Read and understand your Crystal Fire Burner Owner's manual before beginning burner hookups or using the device. Do not use Teflon tape or pipe dope on flare fittings.

- **See Crystal Fire® Plus instructions for burner installation.**
 - All gas connections were completed at the factory.
- Check all connections for leaks. If needed, tighten connection with 2 wrenches and re-check for leaks.
- Attach burner valve to control panel with provided screws as shown below.




- **Connect Ground wire and Electrode wire from burner to sparker.**



- Connect ignitor and ground wire to sparker box. Both wires can connect to either connection point. The unit will operate in either configuration.
- Test system by pushing the button on the igniter. Consult the troubleshooting section of the Crystal Fire® Plus Burner Owner's Manual, if the spark is weak, intermittent, or not present.

- **Drop burner into base.**



- Place burner assembly into recessed opening in base.

- **Install Fire Media**

- Scatter all included glass beads, lava rock, or other approved fire media evenly across entire burner surface.
- Install optional Glass Burner Cover on the burner.



**WARNING: DO NOT OPERATE CRYSTAL FIRE® PLUS
BURNER WITHOUT INCLUDED BEADS OR OTHER
APPROVED FIRE MEDIA**

**WARNING: DO NOT OPERATE CRYSTAL FIRE® PLUS
BURNER WITH BURNER COVER IN PLACE**

IMPORTANT

Please consult your Crystal Fire® Plus instruction manual for detailed instructions and important information related to hooking up your burner, including safety information, proper tightening of connections with two wrenches and full burner setup and lighting instructions. **DO NOT ATTEMPT TO INSTALL CFP2424 BURNER WITHOUT FIRST CONSULTING THE CRYSTAL FIRE® PLUS OWNER'S MANUAL.**

WARNING

After consulting the manual and following instructions, remember; before operating, all gas connections must be fully checked for leaks



WARNING: This product can expose you to chemicals including Carbon Monoxide and Benzene which are known to the State of California to cause cancer or birth defects or reproductive harm. For more information, visit www.P65Warnings.ca.gov

Frequently Asked Questions

What is Supercast?

Supercast is a proprietary blend of fiber glass and polymer fortified concrete. This guide will help inform you about some unique characteristics of a Glass-Fiber reinforced concrete and help you keep it looking like new for years to come.

Supercast Glass Fiber Reinforced Concrete (GFRC) Products Warranty Information

- One year warranty on structure and finish. Cracks that exceed 1/8" displacement in either height or gap and determined to be a product of either material or workmanship, shall be warrantied for a period of 1 year. Non-structural hairline cracks are possible and shall not be considered a manufacturing defect.
- Natural variations in color, shade, porosity, pitting and texture may occur with GFRC products and are considered inherent and valued qualities of the material. Variation in shape and dimension can be up to $\pm 1/4"$.
- Under most conditions, re-staining/resealing is suggested every 2 years using the stain sealer identified on the next page. The frequency is dependent on ambient conditions including, but not limited to: frequency of use, exposure to UV, saltwater, chlorine, hard water, air temperature, and humidity.
- If covering a GFRC item, use a one-way breathable cover as supplied by The Outdoor GreatRoom Company, LLC (OGC) or equivalent. Do not use other materials or objects in order to hold down or secure a protective cover on top or around the GFRC item.
- Using a one-way breathable cover will help keep the finish of the GFRC looking newer longer, but it is still recommended to stain/seal on as outlined above.
- When used in conjunction with a Crystal Fire Plus burner setup, all custom GFRC products are required to operate with an OGC glass guard installed around the burner. The glass guard improves the flame appearance and reduces the risk of unnecessary thermal stress on the GFRC surface. A glass guard is recommended for stock GFRC products.

What makes a concrete fire pit unique?

Your fire pit is handcrafted from Portland cement concrete and reinforced with glass fibers to provide exceptional strength and durability compared to traditional concrete. Supercast is typically 1/3 of the thickness of traditional concrete with 3 times the strength. Each piece offers its own uniqueness; you may notice color variations in your fire pit. This is intentionally done during the molding process in order to create a unique natural appearance which mimics natural stone.

Maintenance Instructions:

To keep your fire pit looking new, we recommend the following:

- Keep covered when not in use to protect from buildup of water, snow, dust, dirt, and debris and direct sunlight whenever possible.
- Do not put the cover on when the fire pit is wet.
- If any colored liquids such as wine or soda are spilled on your top, clean off immediately to avoid possible staining.
- We recommend cleaning your fire pit regularly with a mild mixture of dish detergent and warm water; rinse thoroughly.

How do I reseal Supercast surfaces?

- First clean using a diluted solution of vinegar and water to remove any dirt or debris that may have accumulated on the surface and allow to dry.
- Reseal the surfaces using the stain/sealers below based on the color fire pit you have. Apply the stain/sealer using a foam roller and allow it to cure for 24 hours before exposing to water or use. The stain/sealers can be purchased at any Sherwin-Williams store.
- Minor surface scratches can be removed by using the stain/sealing method above. Clean the area affected and apply the stain/sealer.
- Natural Grey - MN Concrete Custom Grey: H&C Exterior Color Top solvent-based solid color sealer, Tint Base-Deep, satin sheen. The color mix is for 5 gallons, vendor can adjust color amounts based on size being purchased:

BAC Colorant	OZ	32	64	128
W1-White	4	42	-	-
B1-Black	4	47	-	-
R2-Maroon	-	15	-	-
Y3-Deep Gold	2	51	-	-

- White - MCP White: H&C Exterior Color Top solvent based solid color sealer, Tint Base-White, satin sheen. The 1 gallon color mix is:

BAC Colorant	OZ	32	64	128
B1-Black	-	2	1	-
Y3-Deep Gold	-	2	1	-

- Midnight Mist - MCP Raven: H&C Heavy Shield water based solid color enamel/stain, Tint Base-Ultradeep, semi-gloss. The 1 gallon color mix is:

BAC Colorant	OZ	32	64	128
W1-White	-	31	1	1
B1-Black	6	21	-	-
R2-Maroon	-	13	-	1
Y3-Deep Gold	-	30	-	-

- Linen – MCP xx: H&C Exterior Color Top solvent based solid color sealer, Tint Base-Extra White, semi-gloss. The 1 gallon color mix is:

BAC Colorant	OZ	32	64	128
B1 - Black	-	4	1	-
R2 - Maroon	-	1	1	-
Y3 – Deep Gold	-	13	1	-
W1 - White	2	-	-	-
L1 - Blue	-	2	-	-

- Latte – MCP Tavern Taupe: H&C Exterior Color Top solvent based solid color sealer, Tint Base-Deep, satin sheen. The 1 gallon color mix is:

BAC Colorant	OZ	32	64	128
B1 - Black	-	41	-	1
R2 - Maroon	-	8	-	1
Y3 – Deep Gold	-	49	-	1
W1 - White	-	29	-	1

- Earthstone – MCP Griffin: H&C Exterior Color Top solvent based solid color sealer, Tint Base-Deep, satin sheen. The 1 gallon color mix is:

BAC Colorant	OZ	32	64	128
B1 - Black	4	63	-	1
R2 - Maroon	-	30	1	-
Y3 – Deep Gold	4	22	1	-
W1 - White	-	11	-	1

SERVICE PARTS – Supercast Base

CVC-36	3014-0011-NG	Natural Grey
	3014-0011-WT	White
	3014-0011-LN	Linen
	3014-0011-MM	Midnight Mist
	3014-0011-LT	Latte
	3014-0011-ES	Earthstone
CVC-42	3014-0012-NG	Natural Grey
	3014-0012-WT	White
	3014-0012-LN	Linen
	3014-0012-MM	Midnight Mist
	3014-0012-LT	Latte
	3014-0012-ES	Earthstone
CVC-48	3014-0013-NG	Natural Grey
	3014-0013-WT	White
	3014-0013-LN	Linen
	3014-0013-MM	Midnight Mist
	3014-0013-LT	Latte
	3014-0013-ES	Earthstone
CVC-60	3014-0014-NG	Natural Grey
	3014-0014-WT	White
	3014-0014-LN	Linen
	3014-0014-MM	Midnight Mist
	3014-0014-LT	Latte
	3014-0014-ES	Earthstone
CVC-72	3014-0015-NG	Natural Grey
	3014-0015-WT	White
	3014-0015-LN	Linen
	3014-0015-MM	Midnight Mist
	3014-0015-LT	Latte
	3014-0015-ES	Earthstone

SERVICE PARTS – Patch Kits

Color	Kit
Natural Grey	CV-SC-PK
White	W-SC-PK
Midnight Mist	MM-SC-PK
Linen	LN-SC-PK
Latte	LT-SC-PK
Earthstone	ES-SC-PK

Refer to Crystal Fire® Plus instruction manual for burner service parts.

Thank you for purchasing an
Outdoor GreatRoom
Company product!



Warranty: Supercast Glass Reinforced Concrete
Products are covered under a 1- year
manufacturer's warranty. Please visit
[https://outdoorrooms.com/pages/product-
support__product-registration](https://outdoorrooms.com/pages/product-support__product-registration)
to register your product.



9583 217th St. W. • Lakeville, MN 55044
Toll Free: 1-866-303-4028 • Sales@OutdoorRooms.com